

DOSIMETER TABLETS AND SCALE (Ref: 20000473)



TECHNICAL SPECIFICATIONS

- 10 tablets
- UVc value scale expressed in mJ/cm²

These tablets are designed to give a visual indication of the UVc energy density applied to a surface. For best results, we recommend using them for each UVc disinfection cycle, as described below:

- Position the tablets as required. Check that the tablets are placed opposite the UVc disinfection unit.
- Switch on the UVc disinfection unit, as indicated in the instructions for each model.
- Check the dose received by the tablet against the measurement scale. Always read the value immediately after the exposure cycle and within a maximum of 24 hours to ensure an accurate reading. After this time, the tablet will return to its original colour.
- Tablets can only be used once and must not be used for more than one disinfection cycle.

Comment: these tablets are designed purely as a visual reference for the accumulated UVc dose and do not determine the cleanliness of a surface. If a tablet is exposed to the light before use, it should be discarded.